



Cod	N	Ø	→
0872	6	29	52
0873	8	33	52
0874	10	37	58
0875	12	39	64

## Brocha prensada Hogar

Hogar pressing brush. Brosse Hogar serrée.



Cod	N	Ø	→
0850	6	29	59
0851	8	33	62
0852	10	37	70
0853	12	39	76
0854	14	45	78

## Brocha prensada "A Toxa"

"A Toxa" round shape brush. Brosse ronde "A Toxa".



Cod	N	Ø	→
0928	00	15	40
0929	0	18	52
0930	2	21	56
0931	4	25	61
0932	5	27	61
0933	6	29	64
0934	8	32	65

## Brocha de recortar mango madera.

Round cut up brush wooden handle. Brosse à recharger manche en bois.

